

Nikon DSLR Cameras										
Lensbaby Lens	D40 D40x D50 D60 D70	D70s D80 D90 D100	D3000 D3100 D3200 D3300 D3400	D5000 D5100 D5200 D5300 D5500	D7000 D7100 D7200 D7500	D200 D300 D300s D500	D3/ D3x/ D3s D4/ D4s D5	D500 D600 D610 D700 D750	D800 D800e D810 D810a	Df
Burnside 35	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Velvet 56 SE	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Velvet 56	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Velvet 85	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Circular Fisheye	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Trio 28	N/A		N/A		N/A		N/A			N/A
Twist 60	Not Recommended		Not Recommended		Not Recommended	Not Recommended	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer Pro II with Sweet 35 Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer Pro II with Sweet 50 Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer Pro II with Sweet 80 Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer Pro II with Edge 50 Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Spark	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Discontinued										
Composer Pro II with Edge 80 Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer Pro with Sweet 35 Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer Pro with Sweet 50 Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer Pro with Edge 80 Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer Pro with Double Glass Optic	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Muse	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Scout	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Control Freak	Nikon F - M		Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M		Nikon F - AP/ M
Composer with Tilt Transformer	N/A		N/A		N/A		N/A			N/A
Tilt Transformer	N/A		N/A		N/A		N/A			N/A